

TKSTAR APP User Manual


1.Download tkstar gps app software

1.1 Direct Search "TKSTAR" in the Apple App Store/Google Play Store to install the applications on your cell phone.

1.2 Scan the qr code to install the applications on your cell phone.



2.Login the TKSTAR GPS APP



2.1 Select "Log in by IMEI" on the bottom of screen

Server: 2.tkstargps.net
 IMEI : on the back side of cover
 Password: 123456

2.2 Select "Log in by username" on the bottom of screen

Server: 2.tkstargps.net
 Username: provided by sales
 Password: 123456

Note: the username need to be provided by sales, a single user use IMEI log in.

3.Show following interface after log in :



Real-time Monitoring: For real-time tracking, can see the equipment real-time trend.

Historical route : To view the equipment of history on the APP

Geo fence: Set GEO FENCE

Issue command: Set the tracker by SMS or by GPRS

Device message: For equipment alarm information


Device info : Account information

Alarm setting : Alarm information setting

Logout : Log out

4.Set the tracker


Enter the Issue command, Show following interface:




4.1 Send Command By GPRS: As issued by GPRS data transmission

(**Note:** GPRS, the issuance of the first APN Setting, guarantee the equipment on the platform is the online status to send success)


Please click "Send Command By GPRS" to enter following interface:



A: Please click "Common" to enter following interface:



B: Please click "General" to enter following interface:



Note: please remember it, if you modify the password (the password is for SMS not for website)

4.2 Send Command by SMS: For issued instructions issued by the SMS

(**Note:** this function for equipment binding SIM number at first, SIM card number binding need the web platform, in the edit account information, or IMEI Target Info to add a SIM card NO.)

Please click "Send Command by SMS" to enter following interface:

